

CONTACT

VIPP HEADQUARTERS

Snorresgade 22 | 2300 Copenhagen S | Denmark
+45 4588 8800 | info@vipp.com

VIPP HOME - STORE & SHOWROOM

Ny Østergade 34 | 1101 Copenhagen K | Denmark
+45 4588 8815 | cph@vipp.com

VIPP USA LLC SHOWROOM

39 Lispenard Street, 5th floor | New York, NY 10013 | USA
+1 (646) 877 5347 | vippusa@vipp.com

vipp.com

vipp

V.12021

SPÉCIFICATIONS DU PRODUIT

Environment	Usage intérieur uniquement
Matériaux	Marbre, verre, aluminium
Poids	591: 6 kg / 13,22 livres 592: 11 kg / 24.24 lbs.
Alimentation	Cordon en tissu avec une fiche interchangeable
Longueur du câble	2 m / 78.7 pouces
Voltage (V)	220-240V~ 50/60 Hz
Source de lumière	591: LED 7 Watt 592: LED 12 Watt
Classe d'efficacité	A++ - E
Classification IP	20 / lieux secs uniquement
Variateur d'intensité	Niveau de 10 à 100 %


Pour plus de spécifications, visiter vipp.com.

PRODUCT SPECIFICATIONS


Environment	Indoor use only
Materials	Marble, glass, aluminium
Weight	591: 6 kg / 13.22 lbs. 592: 11 kg / 24.24 lbs.
Supply	Fabric cord with interchangeable plug
Cord length	2 m / 78.7 in
Voltage (V)	220-240V ~ 50 / 60 Hz
Light source	591: LED 7 Watt. 592: LED 12 Watt
Energy efficiency	A++ - E
IP class	20 / dry locations only
Dimming	10-100% level

For further specifications, please visit vipp.com

VIPP591 Sculpture Table Lamp Small | VIPP592 Sculpture Table Lamp




DIMENSIONS / DIMENSIONS



VIPP591 Sculpture Table Lamp Small | VIPP592 Sculpture Table Lamp

ASSEMBLY AND USE / ASSEMBLAGE ET UTILISATION



INSTRUCTIONS FOR ASSEMBLY AND USE

ATTENTION: Switch off the power supply before any operation such as replacement of the bulb, cleaning, connection to mains etc.

- 1 Remove the lamp from the packaging, and make sure all protective plastic film has been removed.
- 2 Carefully place the marble lamp base on its final position.
- 3 Place the glass lampshade (a) on top of the light unit (b). Screw until it is tightened.
- 4 To carry the lamp, lift the marble base, not the glass lamp shade.
- 5 Connect the power adaptor to a power socket.
- 6 Turn the lamp on/off by turning the switch on the base.
- 7 Dim the light by turning the switch.

INSTRUCTIONS D'ASSEMBLAGE ET D'UTILISATION

ATTENTION: Coupez l'alimentation avant toute opération telle que le remplacement de l'ampoule, le nettoyage, la connexion au secteur etc.

- 1 Retirez la lampe de son emballage et assurez-vous que l'ensemble du film protecteur en plastique a été retiré.
- 2 Placez délicatement la base de la lampe en marbre dans sa position finale.
- 3 Placez l'abat-jour en verre (a) sur le dessus de l'unité d'éclairage (b). Vissez-le jusqu'à ce qu'il soit bien serré.
- 4 Pour transporter la lampe, soulevez la base en marbre, pas l'abat-jour en verre.
- 5 Branchez l'adaptateur électrique à une prise de courant.
- 6 Allumez/éteignez la lampe en tournant l'interrupteur situé sur la base.
- 7 Atténuez la lumière en tournant l'interrupteur.